

Prolongateur standard HE16 pôles avec connecteurs universels (HE, HAN E, CSH)



Câble 18 G 1,5mm²
Graine PVC



HE Mâle 16 pôles



HE Femelle 16 pôles

Référence	Capot connecteur mâle	Capot connecteur femelle
12611-418-22611		
12611-418-22612		
12611-418-22621		
12611-418-22622		
12612-418-22611		
12612-418-22621		
12621-418-22611		
12621-418-22612		
12621-418-22621		

Armanet

16

Armanet



HE Mâle 16 pôles



HE Femelle 16 pôles

Référence	Capot connecteur mâle	Capot connecteur femelle
12612-418-22612		
12612-418-22621		
12612-418-22622		
12621-418-22611		
12621-418-22612		
12621-418-22621		

Suite références prolongateurs
standards HE16 pôles 17

Armanet



HE Mâle 16 pôles



HE Femelle 16 pôles

Référence	Capot connecteur mâle	Capot connecteur femelle	
12621-418-22622			
12622-418-22611			
12622-418-22612			
12622-418-22621			
12622-418-22621			

Schéma de cablage des prolongateurs standards HE16 pôles

N° borne mâle	N° de fil	N°de borne Femelle
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
10	10	10
11	11	11
12	12	12
13	13	13
14	14	14
15	15	15
16	16	16
PE	VERT/JAUNE	PE