

## Prolongateur standard HE24 pôles avec connecteurs universels (HE, HAN E, CSH)



Câble 25 G 1,5mm<sup>2</sup>  
Graine PVC



HE Mâle 24 pôles



HE Femelle 24 pôles

Référence	Capot connecteur mâle	Capot connecteur femelle
<b>12811-425-22811</b>		
<b>12811-425-22812</b>		
<b>12811-425-22821</b>		
<b>12811-425-22822</b>		
<b>12812-425-22811</b>		
<b>12812-425-22812</b>		
<b>12812-425-22821</b>		
<b>12812-425-22822</b>		

**Armanet**

20

**Armanet**



HE Mâle 24 pôles



HE Femelle 24 pôles

Référence	Capot connecteur mâle	Capot connecteur femelle
<b>12812-425-22812</b>		
<b>12812-425-22821</b>		
<b>12812-425-22822</b>		
<b>12821-425-22811</b>		
<b>12821-425-22812</b>		
<b>12821-425-22821</b>		
<b>12821-425-22822</b>		

Suite références prolongateurs  
standards HE24 pôles 21

**Armanet**




HE Mâle 24 pôles



HE Femelle 24 pôles

Référence	Capot connecteur mâle	Capot connecteur femelle
<b>12821-425-22822</b>		
<b>12822-425-22811</b>		
<b>12822-425-22812</b>		
<b>12822-425-22821</b>		
<b>12822-425-22822</b>		



## Schéma de cablage des prolongateurs standards HE24 pôles

N° borne mâle	N° de fil	N°de borne Femelle
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
10	10	10
11	11	11
12	12	12
13	13	13
14	14	14
15	15	15
16	16	16
17	17	17
18	18	18
19	19	19
20	20	20
21	21	21
22	22	22
23	23	23
24	24	24
PE	VERT/JAUNE	PE